

INSTALLATION OF VENT ASSEMBLY

- A. Insert air inlet tube with (top) up into the 8-5/8" x 9-1/4" opening in outside wall, and over air inlet tube on heater. Flue outlet tube extension fits over the outside of flue outlet tube (Fig. 3).
- B. Push vent assembly forward until flue box is against wall. NOTE: Vent "telescope" into tubes on heater maintaining proper overlap into 29-1/2" thickness wall.
- C. Secure wall plate assembly to wall with screws from parts bag. Caulk top and sides of wall plate only. Leave bottom unsealed for drainage.

