



OVENETTE (shown above) consists of (A) polished aluminum cover (B) steel rack and (C) air-insulated double-wall steel base.

OVENETTE ACCESSORIES include — (D) 7 muffin cups (E) cake pan (F) roasting pan and (G) juice-saver pie pan. The Ovenette and all accessories are included in the complete Ovenette Set.

CARE AND CLEANING

Do not immerse base in water. Wipe with clean, damp cloth and if necessary, use fine steel wool to remove burned particles.

The cake pan, pie pan, roasting pan, muffin cups and wire rack may be washed like all your other utensils. They should be washed in clean, mild suds (strong alkalis dull the polish), then rinsed and dried with a clean towel.

The cover should not be immersed in water unless the thermometer is removed. After ordinary baking, the cover need only be wiped with a damp cloth. The thermometer should be removed occasionally and wiped with a damp cloth. **CAUTION:** Remove thermometer by pressing against underside with wooden spoon or similar blunt instrument.

If cover becomes spattered with fats or juices from roasting meats, be sure to wipe clean as soon as possible. If food particles (especially those containing sugar) should cling to inside or outside of the cover, be sure to remove them before the next baking. This will prevent unnecessary spotting. Very fine steel wool and mild soap will remove most stubborn spots.

Product of
WEST BEND ALUMINUM CO.
 West Bend, Wisconsin

Litho in U.S.A