CLEARANCES

Minimum clearances in inches to combustible materials are

G: Top 0 K: Side 0

L: Bottom 0 M: Rear 1

N: See example below

Clearance M between the rearmost part of the refrigerator and the wall behind the refrigerator

Clearance N on top of the condenser is related to the minimum ventilation height

See Fig 11 and examples below





Fig. 11

Refrigerator model	Overall dimensions			Installation dimensions			Recess dimensions			Distance between top of condenser to top of refrigerator
	Height A	Width B	Depth C	Height h	Width w	Depth d	Height H	Width W	Depth D	e
RM 361 RM 461 RM 661 RM 761 RM 1301	32 15/16 40 13/16 52		24 11/16 24 11/16 24 11/16	32 1/8 40 51 3/16	20 1/4 21 9/16 21 9/16 21 9/16 23 7/16	20 3/16 22 3/4 22 3/4 22 3/4 22 3/4	29 3/4 32 5/16 40 3/16 51 3/8 57 1/2	20 1/2 21 13/16 21 13/16 21 13/16 23 13/16	23 3/4 23 3/4	1 1/4 1 1/4 1 1/4 1/8 1/8

This method of installation and these clearences will give you adeqvate space for servicing and proper installation.






Fig. 12

EXAMPLES

The clearance N for the 361 models is derived at in the following way.

Installation with upper and lower side vents

N=Minimum ventilation height 37 minus installation height 29 9/16 plus distance between condenser top and refrigerator top 1 1/4

N=37-29 9/16+1 1/4=8 11/16

Installation with roof vent and lower side vent

N=Minimum ventilation height 31 minus installation height 29 9/16 plus distance between condenser top and refrigerator top 1 1/4 plus distance between roof surface and roof vent cap 5 1/4

N=31-29 9/16+1 1/4+5 1/4=7 15/16

